









everfit

INSTRUCTION

BFK
800




13. Parts list

<p>1</p>  <p>x1</p>	<p>2</p>  <p>x1</p>	<p>3</p>  <p>x1</p>	<p>4</p>  <p>x1</p>
<p>5</p>  <p>x1</p>	<p>6</p>  <p>x1</p>	<p>7</p>  <p>x1</p>	<p>8</p>  <p>x1</p>
<p>9</p>  <p>x1</p>	<p>10L</p>  <p>x1</p>	<p>10R</p>  <p>x1</p>	<p>11</p>  <p>x1set</p>
<p>12</p>  <p>x1</p>	<p>13</p>  <p>x1</p>	<p>14</p>  <p>x1</p>	<p>15</p>  <p>x1</p>
<p>16</p>  <p>x1</p>	<p>17</p>  <p>x1</p>	<p>18</p>  <p>x1</p>	<p>19</p>  <p>x1</p>
<p>20</p>  <p>x1</p>	<p>21</p>  <p>x1</p>	<p>22</p>  <p>x1</p>	<p>23</p>  <p>M8x15mm</p> <p>x4</p>
<p>24</p>  <p>Ø8mm</p> <p>x8</p>	<p>25</p>  <p>M8</p> <p>x4</p>	<p>26</p>  <p>M8x60mm</p> <p>x4</p>	<p>27</p>  <p>M10x45mm</p> <p>x1</p>
<p>28</p>  <p>Ø10mm</p> <p>x1</p>	<p>29</p>  <p>Ø8mm</p> <p>x1</p>	<p>30</p>  <p>x2</p>	

14. Assembly


1

24 x4  8 mm	25 x4  M8	26 x4  M8x60mm
---	---	--




2




23 x4  M8x15 mm	24 x4  Ø8 mm
---	--







3




4



5




6



13 x1 	14 x1 
27 x1  M10x45mm	28 x1  Ø10 mm


7




27 x2 



MOVING THE DEVICE



LEVELLING



EXERCISE COMPUTER INSTRUCTION MANUAL

KEY GUIDE

MODE Select function you want.

SET(if have) Set value of the selected functions

TIME-DISTANCE-CALORIE

RESET(if have) ressthis buttonto resetcurrentfunctionvalueszero.

RECOVERY(if have) Press this button going into pulse recovery detecting.

FUNCTION

TIME—Press the key until sign of “TIME” display on LCD, the monitor will display the time function on the screen.

SPEED—Pressthe key until signof “SPEED” displayon LCD, themonitor will display the speed function on the screen.

DIST----Pressthekey until signof “DIST” displayon LCD, themonitorwill display the distance function on the screen.

ODO(if have)----Press the key until sign of “ODO” on LCD, the monitor will display the odometer function on the screen.

CALORIE----Press the key until sign of “CAL” on LCD, the monitor will display the calorie function on the screen.

PULSE FUNCTION (if have)

Pressthekey until signof “♥” or “PULSE” displayon LCD,themonitorwill display the pulse rate function on the screen.

If the pulse sensor is contact with ear, clip the sensor to earlobe after rubbing earlobe for several times to ensure maximum circulation before measuring your pulse.

If the pulse sensor is contact with hand, place the palms of your hands on the contact pads before measuring your pulse rate.

NOTE

- 1 . The monitor will shut off automatically, if no sign put into for 3 minutes, all function value will be saved . You can press any key or restart exercising to wake up the monitor
2. If improper display on monitor,please re-install the batteries.
3. battery spec:1.5V AAA or AA(1pcs or 2pcs)



GARLANDO SPA

Via Regione Piemonte, 32 - Zona Industriale D1

15068 - Pozzolo Formigaro (AL) - Italy

www.everfit.it - info@everfit.it